

**THE HOUSE OF ALL
CONSTRUCTION MACHINERY
SPARE PARTS & ACCESSORIES**



**SHRINATHJI
INFRACON**

- **CONCRETE BOOM PLACER PARTS & ACCESSORIES**
- **STATIONERY CONCRETE PUMP PARTS & ACCESSORIES**
- **RMC PLANT TWIN SHAFT & PAN MIXTURE**
- **TRANSIT MIXTURE PARTS & ACCESSORIES**
- **CEMENT & FLYASH STORAGE SILO PARTS & ACCESSORIES**



Spare Parts For Concrete Boom Placer & Stationery Concrete Pump

S Valve HBT 40 C Sany




PRESSURE GAUGE



HYD. GEAR PUMP



CONCRETE PUMPING CYLINDER



CONCRETE PIPE LINE BEND WEDGE TYPE



TAPER PIPE



ROCK VALVE &
ROCK VALVE SHAFT




RAM DM 180



PUMP ACCESSORIES




PUMPING CYLS.



SEAMES PIPE



RUBBER HOSE'S



KIDNEY SEAL



SPECTACLE PLATE



HOUSING LINNING




CONCRETE DELIVERY TUBE



PIPE LINE CUPLINGS



BOOM PLACER WATER PUMP



HYD. DIFFERENTIAL
CYLINDER ASSY.



S. VALVE ASSY.



AGITATOR PARTS



ELBOWS FOR BOOM PLACER



CONNECTION PIPE



DISCHARGE FLANGE ON 150



Spare Parts For Concrete Boom Placer & Stationery Concrete Pump

AGITATOR GEAR BOX



MECHANICAL SHUT OFF VALVE



SWING CYLINDER




AGITATOR SHAFT
DRIVE SIDE PUTZ.



PRESSURE RELIEF VALVE



TORQUE SUPPORT PLATE



SWING LEVER



SK TYPE SEAL




PUMPING PISTON



RAM BANCH



SK TYPE CLAMP



PUTZ S VALVE



SWING CYLINDER & LEVER S 36 PUT




PUMP BALL SOCKET




HOLDING BOLT WITH CAP



GREASING PUMP & DISTUBOTOR



FLAT GATE VALVE ASSEMBLY



PIPE CLEANNG BALL



AGITATOR SHAFTS



FOLDABLE ELBOW



DOUBLE ACT GEAR PUMP



HYD PUMP KITS



CLAMP DN 150 PUTZ




Spare Parts For Concrete Boom Placer & Stationery Concrete Pump

90 DEGREE ELBOW R 275



PIPE LINE BRACKET



ELBOWS



CONNECTING ROD



SK TYPE SEALING RING



PISTON BOLT 350 D



90 DEGREE ELBOW R 275



BOOM CYL. SEAL




ROCK VALVE SHAFT BUSHING



WEDGE TYPE PIPELINE



RAM SEAL PUSANY




S VALVE WEAR SLEEVE



PMP PUMPING PISTON



LEAD




HYD. DIFFERENTIAL CYLINDER



ROCK VALVE ASSY.




SANY UPPERHOUSING



MAGNETIC SENSOR



BOOM PLACER ELBOW




RAM DN 200




HYD. CONCRETE SHUT OFF VALVE



WEAR PLATE SET



OUTER HOUSING



FLANGE BEARING



Spare Parts For Concrete Boom Placer & Stationery Concrete Pump

PIPE LINE FLANGE




S-36 BOOM PLACER REMOTE



SLEWING LEVER



SHELL



HYD COOLER FAN



WEDGE TYPE PIPE LINE



COVER LINING



SEALING CONE



GREASE GUN WITH GREASING DISTRIBUTOR



RAM WITH PIVOT



RPM METER



WEDGE TYPE CLAMP



GROOVED RING



UPPER HOUSING BUSH & DISC



UPPER HOUSING



SPIN HYDRAULIC FILTER




SEAL DN 250



SPECTACLE PLATE SET DN 200



U CLAMP FOR BOOM PLACER



PIPE CLEANING PISTON



GUIDE BUSH C P



AGITATOR MOBILE VALVE CAP



HYDRAULIC 130 CC REXROTH



SOLENOID-VALVE



Spare Parts For RMC Batching Plants Pan Mixutere & Twin Shaft

CENTRAL ARM WITH CAP



SCRAPER BUCKET



DOUBLE ACT. HYD CYL



DRIVE & NON DRIVE SEAL KIT 60



SICOMA CENTRAL ARM



MIXING BLADES & ARMS



WEARING TWIN SHAFT



CENTRAL SHOVEL TWIN SHAFT



SILO ANTI VIBRATION PAD



SICOMA 90 MIXING TIPS



CENTRAL SHOVEL




BOTTOM TILES




LATERAL PLATE TWIN SHAFT



LATERAL BLADE TWIN SHAFT



SKIP BRAKE JOINT COUPLING



CENTRAL ARM TWIN SHAFT



SIDE CLEANER BLADE



CONVEYOR BELT



DISCHARGE RUBBER



GEAR PUMP B.P.



SCRAPER GEAR & MOTOR



SICOMA 60 MIXING TIPS



SAND DISH. GATE



BHS TWIN SHAFT MIXER



Spare Parts For RMC Batching Plants Pan Mixture & Twin Shaft


BHS MIXTURE SEAL KIT H1J



MIXING BLADES WITH ARM



TWIN SHAFT MIXING DRUM



CONVEYER ROLLER WITH BRACKET



WEARING PLATE



CENTRAL SHOVEL



CENTRAL SHOVEL



PALANTRY ARMS & BLADE



SICOMA 60 CENTRAL SHOVEL




SIDE CLEANER BLADE L.H



SIDE CLEANER BLADE R.H



BOTTOM SIDE LINER



MIXING ARM



CENTRAL SHOVEL TWIN SHAFT




SIDE CLEANER BLADE L. H



SIDE CLEANER BLADE R. H



MIXER ROTOR MAC 30




OUTER WEARING PLATE



SILO PRV VALVE



BOTTOM GATE TILES CP 30



MICRO SWITCH BOX



MIXING ARM SET



BOTTOM TILES CP 30



RECTIFIER



Spare Parts For RMC Batching Plants Pan Mixture & Twin Shaft

SCRAPER WINCH DRUM



SILO DUST COLLECTOR ASS.



ADMIXTURE VALVE




RECTIFIER SEW



COVER FOR DISH. DOOR




TROUGH CLADDING TILE INTERIOR




DOUBLE CHANGE OVER RELAY



CABLE WINCH



STRIPPER PLATE



DOUBLE HORN SHOVEL



DUST COLLECTOR FILTER



ARM SUSPENTION



SIDE CLEANER BLADE



HANGER BEARING



THREADED NUT L.H / R.H



MIXING BLADE GREAVES 500



MAC. 30 MIXING BLADE



PNV. SOLENOID VALVE




DISH. GATE THREADED NUT CP 18



MAIN PULLEY




WEARING PLATE



TWIN SHAFT GEAR BOX JOINT COUPLING



PNV SOLENOID VALVE



PUSH BUTTON



Spare Parts For RMC Batching Plants Pan Mixuture & Twin Shaft

SAND VIBRATOR MOTOR



SCREW CONVEYOR ASSY.




MIXING TILES




INDUCT PROXI METIC SWITCH



LIMIT SWITCH



S-TYPE LOAD CELL



HANGER BEARINGS



PNEUMATIC FITTINGS




ACTUATOR VALVE P 101



SCREW CONVEYOR GEAR BOX



MODULE SIWAREX CP 30



PROXI SWITCH



POWER CONTRACTOR



PNEUMATIC CYL.



BOTTOM TILES & ARMS



WEARING PACKING



RECTIFIER CP 30



BUTTER FLY VALVE



WEIGHTING INDICATOR



BUTTERFLY WITH ACTUATOR



CENTRAL SHOVEL



RETAINING RING



BRAKE OIL



Spare Parts For Transit Mixture

FILTER ELEMENT CAP FOR TM



SELF STARTER




GREVES WATER PUMP



T M GEAR BOX BEARING



TM CHUTE ASSEMBLY



RADIAL CONVEYOR



CENTER FLEX COUPLING



MAGNETIC SENSOR



CENTER FLEX COUPLING



TM GEAR BOX



TM HOOD TM ENGINE HOOD



WATER FEEDING COUPLING



DOUBLE COMMON LEVER ASSY.



TM SHUT SUPPORT JACK



HYDRAULIC PUMP COUPLING



DISCHARGE CHUTE



DRUM CARRING ROLLER



TM DRIVE UNIT



WATER VALVE



ENGINE VIBRATION PAD



AIR CLEANER ASSEMBLY



DISCHARGE EXTENSION CHUTE



HYDRAULIC COOLING FAN



V TYPE CHUTE



Spare Parts For Transit Mixture

WATER PUMP



WATER PUMP REPAIRING KIT



WATER TANK



TM CHUTE SUPPORT JACK WITH BEARING



WATER SPRAY NOZEL



NEW MODEL FILTER ELEMENT



DOUBLE COMMON LEVER WIRE



ELECTRIC PANNEL FOR TM



HANDLE-WITH-GEAR-SET



ROLLER DUST COVER



ROLLER-PIN



TRANSIT MIXTURE HYD PUMP KIT




TRANSIT MIXTURE ENGINE PARTS



HYD. HOSES




TRANSIT MIXTURE HYD. OIL FILTER



TRANSIT MIXER DRUM




DOUBLE COMMAND LEVER



WATER PUMP



TM PARTS



HYD. COOLER



GEAR BOX



THERMO SWITCH



CENTAFLEX COUPLING



GEAR BOX SEALS



CONSTRUCTION EQUIPMENTS SPARE PARTS



+91 9929997446 | +91 8562875959
+91 9829101412 | +91 8511059523

info@shrinathjiinfracon.com | shrinathjinfracon@gmail.com

www.shrinathjiinfracon.com

Office : F-109, Sumel Business Park-8 Ajit Mill Cross Road,
Rakhial, Ahmedabad - 380023, Gujarat, INDIA.

Factory Add : Shed No. 1, A Matru Chaya Industrial Estate,
Dhamatwan, Vanch Road, Village - Dhamatwan,
Tal. Dascroi, Ahmedabad - 382435, Gujarat, INDIA.

Office : 6 - E, Mahveer Nagar Opp. FCI Collage,
Sector - 14, Udaipur, Rajasthan.



shrinathjiinfracon

